


L	W	H
11 $\frac{7}{8}$ "	11 $\frac{7}{8}$ "	1"
11 $\frac{7}{8}$ "	11 $\frac{7}{8}$ "	2"
11 $\frac{7}{8}$ "	23 $\frac{7}{8}$ "	1 $\frac{3}{8}$ "
15 $\frac{3}{4}$ "	15 $\frac{3}{4}$ "	1 $\frac{1}{4}$ "
15 $\frac{3}{4}$ "	15 $\frac{3}{4}$ "	1 $\frac{1}{2}$ "
19 $\frac{5}{8}$ "	19 $\frac{5}{8}$ "	2"



ARCHITECTURAL PAVERS PAVER SIZES

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S




P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

DIMENSIONS

GENERAL DETAILS

ENGINEER SEAL:



NOTES:

1. DRAIN MAY BE NECESSARY IN SLOW DRAINING SUBGRADE.
2. BASE THICKNESS VARIES WITH TRAFFIC, CLIMATE AND SUBGRADE CONDITIONS.
3. CONCRETE PAVERS SHOULD BE PLACED ON A CEMENT TREATED BASE IF SOIL IS EXTREMELY WEAK OR CONSTANTLY SATURATED.
4. PLASTIC, STEEL ALUMINUM, OR PRECAST CONCRETE EDGING MAY BE USED.
5. JOINTS SHOULD BE SWEEPED WITH SAND.

**ARCHITECTURAL PAVERS
PEDESTRIAN INSTALLATION**

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

SAND SET

OVER COMPACTED
AGGREGATE BASE



NOTES:

1. EXISTING ASPHALT OR CONCRETE PAVEMENT SHALL BE THOROUGHLY INSPECTED FOR AREAS IN NEED OF PATCHING OR REPLACEMENT. CONDUCT ALL REPAIRS AND FILL ALL CRACKS GREATER THAN $\frac{1}{4}$ " (7mm) WIDE PRIOR TO PLACING GEOTEXTILE, SANDS AND PAVERS.
2. PROVIDE DRAINAGE OF SAND LAYER THROUGH PEA GRAVEL - FILLED WEEP HOLES(S)
3. JOIST SHOULD BE SWEEPED WITH SAND.

**ARCHITECTURAL PAVERS
PEDESTRIAN INSTALLATION**

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

SAND SET

OVER
EXISTING ASPHALT



NOTES:

1. EXISTING ASPHALT OR CONCRETE PAVEMENT SHALL BE THOROUGHLY INSPECTED FOR AREAS IN NEED OF PATCHING OR REPLACEMENT. CONDUCT ALL REPAIRS AND FILL ALL CRACKS GREATER THAN $\frac{1}{4}$ " (7mm) WIDE PRIOR TO PLACING GEOTEXTILE, SANDS AND PAVERS.
2. PROVIDE DRAINAGE OF SAND LAYER THROUGH PEA GRAVEL - FILLED WEEP HOLES(S) OR CATCH BASIN.

**ARCHITECTURAL PAVERS
PEDESTRIAN INSTALLATION**

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

SAND SET

**OVER
EXISTING CONCRETE**



NOTES:

1. CONCRETE SLAB SHALL BE SLOPED TO PROVIDE COMPLETE SURFACE DRAINAGE. PROVIDE SUBSURFACE DRAINAGE AS REQUIRED.
2. SLAB TO HAVE STEEL TROWEL AND FINE BROOM FINISH. DO NOT USE CURING COMPOUNDS. MAXIMUM VARIATION IN SLAB $\frac{1}{4}$ " IN 10'.
3. EXPANSION JOINTS ARE MANDATORY. ARCHITECT MUST SPECIFY LOCATION AND DETAIL ON DRAWINGS.
4. JOISTS SHOULD BE SWEEPED WITH SAND OR GROUT.

**ARCHITECTURAL PAVERS
PEDESTRIAN INSTALLATION.**

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

MORTAR SET

THIN SET
OVER CONCRETE



NOTES:

1. USE OF MORTAR IN NOT RECOMMENDED IN FREEZE - THAW CONDITIONS.

STAIR TREADS AND RISERS

DRAWN BY: O100 DESIGN

DATE DRAWN:


REVISION DATE:

DRAWING SCALE: N.T.S



P. O. BOX 5982
 LOS ANGELES, CA 90055
 TEL: 213-380-5560 FAX: 213-380-5561
 www.TileTechPavers.com

ENGINEER SEAL:



NOTES:

1. CONCRETE SLAB SHALL BE SLOPED TO PROVIDE COMPLETE SURFACE DRAINAGE.
PROVIDE SUBSURFACE DRAINAGE AS REQUIRED.
2. SLAB TO HAVE STEEL TROWEL AND FINE BROOM FINISH. DO NOT USE CURING COMPOUNDS. MAXIMUM VARIATION IN SLAB 1/4" IN 10'.
3. EXPANSION JOINTS ARE MANDATORY. ARCHITECT MUST SPECIFY LOCATION AND DETAIL ON DRAWINGS.

**ARCHITECTURAL PAVERS
VEHICULAR INSTALLATION**

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

MORTAR SET

THIN SET
OVER CONCRETE



NOTES:

1. CONCRETE SLAB SHALL BE SLOPED TO PROVIDE COMPLETE SURFACE DRAINAGE. PROVIDE SUBSURFACE DRAINAGE AS REQUIRED.
2. SLAB TO HAVE STEEL TROWEL AND FINE BROOM FINISH. DO NOT USE CURING COMPOUNDS. MAXIMUM VARIATION IN SLAB $\frac{1}{4}$ " IN 10'.
3. EXPANSION JOINTS ARE MANDATORY. ARCHITECT MUST SPECIFY LOCATION AND DETAIL ON DRAWINGS.

**ARCHITECTURAL PAVERS
VEHICULAR INSTALLATION**

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

MORTAR SET

THICK SET
OVER CONCRETE



NOTES:

1. INSTALLATION OF TACK COAT SHOULD BE DONE ACCORDING TO MANUFACTURERS. INSTRUCTIONS TO ASSURE PROPER BONDING AND TO PREVENT WATER FROM GETTING UNDERNEATH PAVERS.
2. JOINTS SHOULD BE SWEEPED WITH SAND.

ARCHITECTURAL PAVERS
VEHICULAR INSTALLATION

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:




DRAWING SCALE: N.T.S

ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

BITUMINOUS



ARCHITECTURAL PAVERS EDGE INSTALLATION


DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:




P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

EDGE DETAILS (PART 1)


- A. PLASTIC
- B. ALUMINUM / STEEL
- C. PARTIAL DEPTH PRECAST



D



F



E

ARCHITECTURAL PAVERS EDGE INSTALATION


DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

EDGE DETAILS (PART 2)

D. TROWELED CONCRETE EDGE
E. PRECAST CONCRETE / STONE
F. PRESSURE TREATED TIMBER



ARCHITECTURAL PAVERS SLOPE PROTECTION

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:


DRAWING SCALE: N.T.S



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

SLOPE PROTECTION

ENGINEER SEAL:



NOTES:

- 1. INSULATION MAY BE EXCLUDED FOR SOME APPLICATIONS
- 2. JOINTS SHOULD BE SWEEPED WITH SAND

ARCHITECTURAL PAVERS ROOF DECK INSTALLATION

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

NONE PEDESTAL

FIELD DETAILS



PEDESTAL PAVER SYSTEM ROOF DECK INSTALLATION

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S

ENGINEER SEAL:





P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

ADJUSTABLE HEIGHT
PEDESTALS

LEVEL SURFACE
OVER SLOPE

ROOF WALL JUNCTURE.

DECK RAIN.



PEDESTAL PAVER SYSTEM
ROOF DECK INSTALLATION

DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S


ENGINEER SEAL:



P. O. BOX 5982
LOS ANGELES, CA 90055
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

ADJUSTABLE HEIGHT
PEDESTALS

EDGE DETAILS



PEDESTAL PAVER SYSTEM ROOF DECK INSTALLATION

DATE DRAWN BY: O100 DESIGN

DATE DRAWN:

REVISION DATE:

DRAWING SCALE: N.T.S



1914 WEST PICO BLVD.
LOS ANGELES, CA 90006
TEL: 213-380-5560 FAX: 213-380-5561
www.TileTechPavers.com

FIXED HEIGHT
PEDESTALS

FIELD DETAILS

ENGINEER SEAL: